

# Work Order ID 63803

Monday, November 15, 2010 8:34:05 AM

Page 1

Item ID: D350-616-011

Accept

Setup Start

Revision ID:

Stop

Item Name: Emergency Stretcher

Start Date: 11/15/2010 Start Qty: 1.00

Cust Item ID:

Required Date: 11/22/2010 Req'd Qty: 1.00

Customer:

Reference:

Approvals:

Process Plan:

Date: 10/11/15

Tooling:

Date:

Run Start

QC:

Date:

SPC (Y/N):

Date:

Stop

Sequence ID/  
Work Center ID

Operation  
Description

Set Up/  
Run Hours

Tool ID

Tool #

Plan  
Code

Accept  
Qty

Reject  
Qty

Reject  
Number

Insp.  
Stamp

Draw Nbr

Revision Nbr

d350-616

E

0.00

0.00

0.00

0.00

0.00

0.00

100



DC

Document Control

Memo

Photocopy bluefile and create labels per PPP D350-616-011  
CHG004

8/10/12/13

CK for CL 10/12/13

110



Packaging

Packaging

Pick Kit

Memo

10/12/13

120



QC

Quality Control

QC4- 100% Inspect kits for completeness

Memo

8/10/12/13

70

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

**Work Order ID 63803**

Page 2

Monday, November 15, 2010 8:34:05 AM

Item ID: D350-616-011

Accept



Setup Start



Revision ID:

Stop



Item Name: Emergency Stretcher

Start Date: 11/15/2010 Start Qty: 1.00



Cust Item ID:

Required Date: 11/22/2010 Req'd Qty: 1.00



Customer:

Reference:

Run Start



Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_

Stop



QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
	Packaging								
Packaging	Memo Identify and pack for shipping as per PPP D350-616-011 Location: <u>2E</u> PPP Rev: _____	0.00							
140	QC21- Final Inspection - Work Order Release	0.00							
	QC								
Quality Control	Memo	0.00							

10/12/13

CK 10/12/13

MF  
10-12-13

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

Monday, November 15, 2010 8:34:10 AM

Page 1

Work Order ID: 63803



Parent Item: D350-616-011



Parent Item Name: Emergency Stretcher

Start Date: 11/15/2010

Required Date: 11/22/2010

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP E03.04.04 Reformat KJ/RF  
IPP Rev:F 08-12-10 rev.E as per dwg DD verified by:ec

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
<i>S</i> D2370 		Manufactured	No	①			Each	0.0000	1	1			
Litter Assembly													
D2493 		Manufactured	No	①			Each	0.0000	1	1			
Patient Stop Assembly													
D350-616-013 <i>CHGR</i> 		Manufactured	No				Each	2.0000	1	1			
Deck Plate and Tie Down 													

## Location

FG031

61560

61562

## Loc Qty

2

1

1

## Loc Code

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

*B60966 10/12/13*  
*B64568 10/12/13*  
*B61560 10/12/13*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# REFERENCE ONLY

QTY - 011	Qty - 013	Qty - 015	Part Number	Description
X			D350-616-011	Full Litter Kit
1	X		D350-616-013	Deck Plate and Tie Down Kit
	1	X	D350-616-015	Deck Plate Kit
		1	D2344	DECK PLATE (AFT)
		4	D2348	WEAR PLATE (KEY WAY)
		1	D2353	STIFFENER
	1		D2360	LITTER TIE DOWN (LOCKING)
		1	D2364	DECK PLATE (FWD)
		2	D2365	WEAR PLATE (PIP PIN)
		1	D2369-1	LOCATOR PLATE
		1	D2369-3	LOCATOR PLATE
1			D2370	LITTER ASSEMBLY
1			D2493	PATIENT STOP
	1		D3179-041	LITTER TIE DOWN (NON-LOCKING)
		1	D3494-1	STUB COVER
		25	MS20426AD4-5	RIVET
		25	MS20426AD4-6	RIVET
		6	MS20426AD5-7	RIVET
		6	MS20426AD5-8	RIVET
		15	MS20601AD4W2	BLIND RIVET (or CR9162-4-2)
		30	MS20601AD4W3	BLIND RIVET (or CR9162-4-3)
		6	MS21042L3	NUT (or MS21042-3)
		6	MS24693-C273	SCREW (or MS24693-273)
		22	MS24693-C48	SCREW (or MS24693-48)
		4	MS35207-264	SCREW
		10	NAS1149D0363J	WASHER (or AN960JD10)

**RELEASED**  
08/11/21

CANADA  
DEPARTMENT OF TRANSPORT  
AIRCRAFT CERTIFICATION  
BRANCH  
DAO # 01-O-01

APPROVED

BY: [Signature]  
D. SHEPHERD (DE # 02)

DATE: 08.11.07  
CERT. NO.: SH96-10  
ISSUE NO.: 2

E	MAKE DSI 9310 STANDARD; D3179-041 REPLACES D2350	RF	08.11.07
D	ADD D3494-1 STUB COVER	MB	06.01.19
C	ADD DSI 9112/9117/9130/9236/9310	MB	06.01.10
B	ADD VIEW OF D2493 TO SHEET 9	BW	96.01.09
A	NEW ISSUE	BW	95.02.20
REV.	DESCRIPTION	BY	DATE
DESIGN	BW	<b>DART AEROSPACE LTD</b>	
DRAWN	RF	HAWKESBURY, ONTARIO, CANADA	
CHECKED	DS	DRAWING NO.	REV. E
MFG. APPR.	N/A	D350-616	SHEET 1 OF 12
APPROVED	DS	TITLE	SCALE
DE APPR.	[Signature]	AS350/355 LITTER KIT INSTALLATION	NTS
DATE	08.11.07	COPYRIGHT © 1995 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.	